




1. Fixe o trilho no armário.
2. Fixe o sistema de trava embaixo da gaveta.
3. Coloque o fundo da gaveta no deslizamento, em seguida, empurre a gaveta para dentro do armário.
4. Para retirar, pressione e segure a trava, e puxe a gaveta para fora.

The drawing shows the L-Series profile with the following dimensions:

- Top View (Side View):**
 - Overall width: 250
 - Distance from Borda do Gabinete to first hole: 37
 - Distance between first and second hole: 32
 - Distance between second and third hole: 96
 - Distance between third and fourth hole: 64
 - Profile length: L-250
- End View (Front View):**
 - Profile height: 2
 - Overall length: 300
 - Distance from Borda do Gabinete to first hole: 37
 - Distance between first and second hole: 32
 - Distance between second and third hole: 96
 - Distance between third and fourth hole: 64
 - Profile length: L-300
- Other Views:**
 - Profile length: L-350 (350)
 - Profile length: L-400 (400)
 - Profile length: L-450 (450)
 - Profile length: L-500 (500)
 - Profile length: L-550 (550)
- Bottom View (Front View):**
 - Overall width: 320
 - Distance from Borda do Gabinete to first hole: 37
 - Distance between first and second hole: 32
 - Distance between second and third hole: 128
 - Distance between third and fourth hole: 224
 - Distance between fourth and fifth hole: 288
 - Distance between fifth and sixth hole: 320